




COMPOSITE MOTORCYCLE STAND

This Composite Stand with it's many features should provide years of race worthy service when properly maintained.



TOOLS NEEDED:

Phillips Head Screwdriver

**ASSEMBLY SHOULD TAKE 5 MIN. TO 10 MIN.
WITH PROPER TOOLS.**

1) Secure mat to motostand top using 8 M5 x 16 screws.

2) Flip motostand top over to secure legs.

In the image you will notice how the handle corresponds with the leg. The handle needs to be in place before leg installation. Snap leg in position as shown. Secure leg to top with provided M5 x 25 Screws. Repeat step on other 3 legs.

Note: Screws should be secure, however be sure not to over tighten.

3) Now take the tray and slide it down between legs until the holes line up. Secure with provided M5 x 16 Screws.

Note: Screws should be secure, however be sure not to over tighten.

Composite Motorcycle Stand made by Cycra in the USA

 M5 x 25
Plastic Screws
Qty. (4)
  M5 x 16
Plastic Screws
Qty. (16)



If you have problems or questions please call our tech line at 1-800-448-1223 weekdays 9:00 AM to 5:00 PM est.

DO NOT OVER TIGHTEN ! HAND TIGHTEN ONLY!